



REFRIGERATOR



CABINET PARTS

IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
						1101		
1	2314273		2 3		Hinge (Top) Roller, Front (2)	35	2201014	Corner Filler (2) White
	2302180		4		Cabinet (Not a Serviceable Part)		2200926 2201017	
	2302037 2225623		5	489385	Clamp, Tube (Water Supply Line)	36		Grille (Includes
		Service Sheet	6	489427	Screw			Illus. 39)
	2225413	Customer	10	2179826	Rivet		2254313	White
		Instructions	11	3400504	Screw		2254316	Biscuit
			12	549193	Clamp, Cord		2254315	Black
Following May Be Purchased		15	489497	Screw	37	489341	Washer	
	D-IT-YOU	IDSELE	16	2183972	Hinge, Center	38	487576	Washer
	EPAIR MA	_	17		Shim, Hinge Center	39 40	2189356	Clip, Grille (2) Cover, Hinge
	677969	Do-It-Yourself Manual Ref./Frz.	18 20 24	8281265 2254473	Screw Hinge Butt Fitting, Water Tube		2213360 2213364 2213363	Biscuit
			27		(Not Serviced) Hole Plug (6)	41		Rail, Center (Not Serviced)
				2201012 2200924 2183998	Biscuit	44	2202884	Cover, Unit


DOOR PARTS



DOOR PARTS

Illus			Illus.			Illus		
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1		Refrigerator Door	13		Nameplate	25	2204812	Bin, Door Shelf
		(Includes	16		Trim, Door Shelf	26	2189202	Bracket,
		Illus. 3,4,9	17	8281206				Door Stop (2)
		& 22)	19		Freezer Door	27	488921	Screw
	2183920	White			(Includes	28		Hole Plug
	2205284	Biscuit			Illus. 4,22 & 23)		2212648	White
	2200714			2182489			2212649	Biscuit
2		Handle, Trim		2204686			2212651	Black
	2193353W	White		2200711		29	2156007	Plug, Trim
	2193353T	Biscuit	20		Hole Plug,	30	2156006	Plug, Trim
	2193353B				Handle	31	2218118	Compartment Door
3		Screw Anchor		2189000		33		Handle,
4	2183198	Tap Plate		2200936				Freezer
5		Handle,		2189009			2213111W	
		Refrigerator	21		Shelf, Flip-Up		2213111T	Biscuit
	2213112W	White	22	2183003			2213111B	
	2213112T	Biscuit	23		Door Gasket,	37		Trim, Door (2)
_	2213112B			0044007	Magnetic	41		Endcap (4)
6	489357				Mist Beige	42	2195948	Trim, Door
8	8281146			2214969	Віаск			
9		Door Gasket,						
	0000075	Magnetic						
	2202875	Mist Beige						
	2202882	Black	l			ı		


LINER PARTS



LINER PARTS

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A
2 3	2197380 2254360	Gasket, Evaporator
4 5	2314156 2212485	Cover (2) Defrost Timer Thermostat Tube Barrier
6 7	488208 2187880	Screw
8 9 10 11 12 13	2162085 2179858 2214986 2163777 2200820 2200859	Socket, Light Damper, Air Fan Motor Fan Blade Control Box
14 16 17 18 19 20 21	489478 2254263 527949 2200831 1118894 2179859 2176281	Screw Cover, Evaporator Light Bulb (2) Weight, Thermal Switch, Rocker Arm
22 23 24	2200863 2254354 2189452	Knob, Thermostat Air Tower Air Diffuser,
25 26	2314158 2212439	Air Separator
29	2254453	Assembly Bracket, Fan Motor
31 32	2204639 2254454	Shield, Heat
33	2176341	Clip, Defrost Timer
34 35	2302536 2163810	Knob, Damper Bracket,
36	2205079	Damper Knob Seal, Rear
37	940014	Thermostat Hole Plug, Control Box
38 39	2210509 2310043	

UNIT PARTS



Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	2225596	Plate, Unit Mounting	21 22	3400518 488500		Follo	wing Pa	arts Not Illustrated
2	2169104	Insulation, Sound Dampening	26	2183454				Parts Not Included
3 4		Condenser Heater, Defrost	28	2225833			978025	Valve, Access (1/4")
5 6		Evaporator Assy.			Illus. 12,13,14, 26,29,31 & 33)		978026	(1/4) Valve, Access (5/16")
7 9	2254295	Drain Pan Bracket, Heater			(Also Order 482801 Installation Kit		978027	Valve, Access (3/8")
10		Extension, Air Baffle	29		& 876765 Tube Kit) Drier		978028	Valve, Access (1/2")
11 12	2255113 4387731	Strap		2199167 4387019	Production		978029	Valve, Access
	1001101	(Service Only)	30	2155774			978030	(5/8") Valve, Access
13	4390624	Overload (Service Only)	31	2169373	Capacitator Production			(3/4") Valve, Access
14		Grommet (4) Production	33	1118576 4387765	Wire Assembly		070704	(3/16")
15	4387558 2225785	Service Start–Device Combination	39 40		(Service Only) Air Baffle Motor, Condenser	REF	RIGERA	NT CHARGE
		(Start Relay and Overload for	42		Wire Assembly, Unit			4.00 Ozs. (R134A)
		Production Compressor Only)	43 46		Fan Blade Tube, Discharge			(1110 111)
16	2201185	Support Block	47		Tube, Suction			
17	2150304	Roller (2)	48		Tube, Process			
18	2221797		58	2300635	Tray, Evaporator			
19 20	2182338 489373	Clip, Heater Screw						



ICEMAKER PARTS

ICEMAKER PARTS

Illus. No.	Part No.	DESCRIPTION
1 3 4 5 7 10 11 18 19 20	488878 2210495 2181939 628379 2181943 2188782 627018 2210484 489464 628228	Mold & Heater
22 23 24 25 26	628356 2194711 2182124 2194712 627796	Assembly (Also Order 542638 Silicone Grease) Cup, Water Fill Ejector Ice Striper Support Retainer
27	627985	Thermostat Thermostat (Also Order 542369 Cement Alumilastic)
28 30 31 32 33 35	8533917 489276 627792 2187464 628320 628399	Screw Screw Shut Off Arm
36 38	489478 489136	Screw Screw,
39 40 100	488208 488886 4317943	3–24 x 23/64 Screw Screw, 8–18 x 1/2 Icemaker,Complete Assembly

SHELF PARTS

For Models: ET1CHMXKQ05, ET1CHMXKT05, ET1CHMXKB05 (White) (Biscuit) (Black) 17 23 Illus. **Part** No. **DESCRIPTION** No. 13 2210522 Shelf, Ladder (2) 2300520 Shelf, Ladder 1 2 Center 2163762 Cup, Shelf Mtg. 489478 Screw 2216624 Egg Bin 6 2176222 Slide, Humidity Control 8 2212446 Body, Humidity 21 Control 2210526 Crisper Cover 9 2201102E Shelf, Cantilever 10 2210573 Insert, Crisper 11 Cover 13-2201106 Pan, Shelf 12 25 Cantilever 2200987 Glass, Shelf 2188685 Trim, Shelf Front 13 20 14 2163832 Crisper Support 15 2184667 Shelf, Freezer 17 2218132K Pan, Meat 20 13 2188711 Trim, Shelf Side 21 23 2254352 Bucket, Ice 2218141 Crisper Pan 24 (Includes Illus. 7 & 8) 2188687 Trim, Shelf Rear 25 25 6 -13 10 11 21 15 24 24

OPTIONAL PARTS
For Models: ET1CHMXKQ05, ET1CHMXKT05, ET1CHMXKB05
(White) (Biscuit) (Black)

Illus. Part No. No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION		
Parts Not Illustrated and		Cust	Customer Touch-Up Material			TORX SCREW WRENCH			
	arts (Not Included)	*350942 Primer, White			1117510 Torx Key				
Miscellane 97894	1 Insulation, Fiberglass (63–1/2" x 35–1/2"		*350930	(12 Oz. Spray Can) Enamel, Black (12 Oz. Spray Can) Enamel, White (12 Oz. Spray Can) Enamel, Biscuit (12 Oz. Spray Can)			•		
21264	x 2–5/8") 3 Sealer, Gum (4 Feet)			Brush Touch-Up Kit (White)					
47950	2 Tape, Úinyl			Brush Touch-Up Kit (Black)					
87630	(3/4" x 108") 5 Kit, Insulation (14 Pcs.		4392899	Brush Touch-Up Kit (Biscuit)					
87602 50558 51187	3" x 24" x 48") 0 Kit, Insulation (2 Pcs. 3" x 24 " x 48") 9 Kit, Foam Slab (30" x 32–1/2" x 1–1/2") 7 Sealer, Mastic (1 Qt.) 3 Touch–Up, White Porcelain (2 Oz.) 8 Grease, Silicone	Refi	799344 4392900 786032	Material Enamel, White (1 Qt. Uncut) Enamel, Biscuit (1 Qt. Uncut) Enamel, Black (1 Qt. Uncut) Kit, Terminal Connector					
	(1/2 Oz.) 9 Cement, Alumilastic (1–1/4 Oz.)	not t may	to be used make co	he spray paint is I where the paint ntact with the door					
60675	5 Bag, Insulation (36–5/8" x 46")	gasl	cets.						
79983	3 Kit, Evaporator Repair (Aluminum Epoxy)								
79983	2 Kit, Porcelain Repair (White)								
50369	5 Cork Sealer								

(1/4 Pound)